



عربة MFR/Brand	Item No.	Item No. (Cross Ref.)	f	F	O	Vehicle Type	Year
Honda	HO-1-04-019	HO-1-04-019	28	32	60	Accord All V6	90-97
Honda	HO-1-04-018	HO-1-04-018	26	30	49	Accord 16V 1.5L	84-89
Honda	HO-1-04-017	HO-1-04-017	26	30	49	EF2 EF6	87-92
Honda	HO-1-04-017	HO-1-04-017	26	30	49	Civic DX CX LX SOHC 1.5L	88-91
Honda	HO-1-04-017	HO-1-04-017	26	30	49	16V CRX DX SI 1.6L	88-91
Honda	HO-1-04-017	HO-1-04-017	26	30	49	Civic (EXC H/B) 4WD	88-90
Honda	HO-1-04-017	HO-1-04-017	26	30	49	Honda CAI EXC ALB	85-89
Honda	HO-1-04-016	HO-1-04-016	26	32	49	EF3 EF4 EF5 EF7	87-92
Honda	HO-1-04-016	HO-1-04-016	26	32	49	Integra All 16VI	86-89
Honda	HO-1-04-016	HO-1-04-016	26	32	49	Honda CA 2,3,5,6	85-89
Honda	HO-1-04-016	HO-1-04-016	26	32	49	Accord LXI A/T MT	84-89
Honda	HO-1-04-016	HO-1-04-016	26	32	49	Prelude AB BB BAI	84-87
Honda	HO-1-04-015	HO-1-04-015	23	27	49	Civic 1.5L M/T W/4 Spd	88-92
Honda	HO-1-04-015	HO-1-04-015	23	27	49	Civic 1.3L M/T W/4 Spd 3DR	84-87
Honda	HO-1-04-015	HO-1-04-015	23	27	49	Civic CRX 1.5L HF	88-91
Honda	HO-1-04-015	HO-1-04-015	23	27	49	Civic GA1	86-
Honda	HO-1-04-015	HO-1-04-015	23	27	49	Civic 4WD	88-89
Honda	HO-1-04-011	HO-1-04-011	26	32	49	Accord SET	84-85
Honda	HO-1-04-011	HO-1-04-011	26	32	49	Prelude SEL 2.0L	85-87
Honda	HO-1-04-011	HO-1-04-011	26	32	49	Honda AD	83-86
Honda	HO-1-04-009	HO-1-04-009	23	30	49	Civic S DX SI	96-
Honda	HO-1-04-009	HO-1-04-009	23	30	49	Civic 1300/1500	84-87



Outer C.V .Joint

Honda	HO-1-04-009	HO-1-04-009	23	30	49	Civic CRX DX SI	84-87
Honda	HO-1-04-009	HO-1-04-009	23	30	49	City 1.3L (GA2□	86-
Honda	HO-1-04-009	HO-1-04-009	23	30	49	AH AK	84-87
Honda	HO-1-04-008	HO-1-04-008	26	32	49	Prelude	83-84
Honda	HO-1-04-007	HO-1-04-007	26	32	49	Prelude	83-84
Honda	HO-1-04-006	HO-1-04-006	24	30	47	Accord	82-85
Honda	HO-1-04-006	HO-1-04-006	24	30	47	Prelude 5spd. DX	83-87
Honda	HO-1-04-004	HO-1-04-004	24	30	45	Civic 1.3L M/T	84-